

DIY WALL MURALS instructions

FIRST STEP

Define the borders of the area where you want to apply the wall murals using some common masking tape.



SECOND STEP

Apply generously and evenly by brush on the area you want to decorate a common wallpaper adhesive: follow the instruction given from the manufacture on how to prepare the paste.

THIRD STEP

Apply the printed side of your DIY wall mural directly on the area previously spread with adhesive. Remove the masking tape around the boundary.




FORTH STEP

Make sure to stick the wall mural completely by patting it down energetically using either a semi-rigid brush or a dry sponge. Wipe off any extra adhesive you may find around the margins.

FIFTH STEP

Once the wall mural has stuck completely down on the wall, start to dump the back support using a wet sponge. During this stage you will notice that the back support will start to separate from the picture itself.



SIXTH STEP

Carefully remove the back support, paying attention not to pull out the picture from the wall. If you face any problem, keep patting the wall mural with the wet sponge.

SEVENTH STEP

Once you have removed the back support use a slightly damp sponge to pat the picture to make sure it will stick evenly to the wall. It will start to appear in all its beauty. Let it dry for at least 48 hours.



EIGHTH STEP

You can decide to leave the wall mural as it will look like in the end or apply a protective layer of gloss or satin varnish as you prefer.